#### ADVANCED PURITY SOLUTIONS

# ErgoNOW<sup>™</sup> Bottle System Key-Coded Connector Upgrade Kit

Accessory kit used to upgrade the SmartProbe<sup>®</sup> bottle system key-coded connector to an ErgoNOW connector

This kit is used to upgrade an existing SmartProbe® connector to an ErgoNOW<sup>™</sup> connector. The ErgoNOW connector provides additional benefits compared to the SmartProbe connector. The ergonomically designed handle disengages the connector locks and releases the connector from the bottle system in a single, smooth motion, improving the ease of use for operators. In addition, the connector's keyed retainer assists in aligning the sensor to the sensor target on the SmartCap<sup>™</sup> closure. ErgoNOW connectors are designed for use with the NOWPak<sup>®</sup> liner-based bottle system or PDMPak<sup>®</sup> bottle system for pressurized applications.

Note: When upgrading a SmartProbe connector to an ErgoNOW connector, both the NA-117 upgrade kit of choice and an ErgoNOW replacement keyed retainer must be ordered. The ErgoNOW PA-12-XXYYZZ (Delrin), PA-13-XXYYZZ (Noryl), PA-14-XXYYZZ (Ultem 1000), or PA-15-XXYYZZ (PEEK) keyed retainer should be ordered to match the key code of the original SmartProbe connector or intended chemistry. SmartProbe and ErgoNOW keyed retainers are not interchangeable.

## **APPLICATIONS**

- PL-type ErgoNOW connectors provide indirect pressure assist or pump delivery of chemical using the NOWPak liner-based bottle system.
- PD-type ErgoNOW connectors provide indirect pressure dispense using the PDMPak bottle system.



ErgoNOW connector safely and securely provides pressure assist or pump dispense

# **FEATURES & BENEFITS**


Key-coded system	Helps prevent dispensing the wrong material
Snap on/easy release design	Provides easy installation and removal of the connector
Self-centering keyed retainer	Ensures perfect alignment of the connector with the SmartCap closure
LED	Provides visual indication that the connector is installed correctly (for connectors with the sensor option)
Standard pressure relief valve	Provides safer system operation
Safety interlock	
mechanism	Prevents connector from accidental release during pressure dispense operation
2	



# **SPECIFICATIONS**

Materials of construction	Connector body	Polypropylene			
	Gas inlet fitting	Stainless steel			
	Nozzle	Stainless steel			
	Nozzle O-ring	EPDM			
	Spring	Stainless steel			
	Screws	Stainless steel			
	Washers	Stainless steel			
	Cable tie down	LDPE			
	Danger label	Polycarbonate			
	Plug	LDPE			
	Strain relief	Nozzle	Nylon		
		Bracket	Polypropylene		
		Screws	Stainless steel		
Manufacturing standards	Fabricated and tested in a Class 5 Cleanroom as per International Standard ISO 14644-1:* Cleanrooms and associated controlled environments – Part 1: Classification of air cleanliness.				
Upgrade limitations and compatibility	SmartProbe connect interference betweer	ting option P cannot be upgraded due to connector handle.			
	SmartProbe connectors with liquid-out fitting options F and H (Flaretek® fitting) require ErgoNOW connector upgrade strain relief option Z (without strain relief) due to height alignment issues between the fitting and strain relief.				
	ErgoNOW connector	r upgrade strain relie	ef option Z (without strain relief) due to height		
Packaging	ErgoNOW connector alignment issues between Each NA-117-XX upg hardware to upgrade to important notes o	r upgrade strain relie ween the fitting and rade kit contains the an existing SmartPi n page 3 for suppor rhole kit double bag	ef option Z (without strain relief) due to height strain relief. e ErgoNOW connector and most supporting robe connector to an ErgoNOW connector. Refer ting hardware guidance. Components are bagged ged and heat sealed. Shipping is performed in a		
Packaging Labeling	ErgoNOW connector alignment issues betw Each NA-117-XX upg hardware to upgrade to important notes o in groups, with the w corrugated containe	r upgrade strain relie ween the fitting and rade kit contains the e an existing SmartPr n page 3 for suppor rhole kit double bag r with a PE bag actin	ef option Z (without strain relief) due to height strain relief. e ErgoNOW connector and most supporting robe connector to an ErgoNOW connector. Refer ting hardware guidance. Components are bagged ged and heat sealed. Shipping is performed in a		
	ErgoNOW connector alignment issues betw Each NA-117-XX upg hardware to upgrade to important notes o in groups, with the w corrugated containe Each shipping cartor	r upgrade strain relie ween the fitting and rade kit contains the e an existing SmartPr n page 3 for suppor rhole kit double bag r with a PE bag actin	ef option Z (without strain relief) due to height strain relief. e ErgoNOW connector and most supporting robe connector to an ErgoNOW connector. Refer ting hardware guidance. Components are bagged ged and heat sealed. Shipping is performed in a ig as the liner.		

\*ISO standard certification is kept up to date as necessary to remain current and effective to be able to demonstrate compliance with up-to-date ISO requirements.



#### **Common Components**

ltem	Qty	Item description
1	1	Connector body assembly, ErgoNOW pump dispense with pressure assist
2	1	Nozzle, shouldered
3	1	Spring, compression
4	1	O-ring, nozzle, EPDM, 70 durometer
5	1	Label, "DANGER," with tie, LDPE, yellow, 0.15" LG (tie not shown in drawing)
6	1	Plug, sensor port, LDPE
7	1	Cable tie down, push mount
8	1	Tee fitting, $\frac{1}{8}$ " NPT × #10-32 UNF × $\frac{5}{32}$ " OD QC
9	1	Valve, pressure relief, stainless steel, 7 psi
10	1	Gas inlet fitting*
11	1	Body, strain, relief**
12	1	Nut, strain, relief**
13	1	Bracket, strain, relief**
14	2	Screw, socket head cap, #10-32 $\times$ 0.50**
15	3	Screw, socket head cap, $\#8-32 \times 0.50$
16	3	Washer, split lock, #8
17	1	Probe***
18	1	Liquid out fitting***
19	2	Seal, O-ring***
20	1	Retainer, keyed, shouldered, nozzle, 3-screw****

Important notes:

\*Refer to gas inlet fitting tabulation on page 5.


\*\* Items 11 – 14 are only included with the A or B strain relief options (see page 6, Ordering Information).

\*\*\* Items 17 – 19 are not included in the upgrade kit. These components are to be reused from the existing SmartProbe connector.

<sup>\*\*\*\*</sup> Item 20 is not included in the upgrade kit. When upgrading a SmartProbe connector to an ErgoNOW connector, both the NA-117 upgrade kit of choice and an ErgoNOW replacement keyed retainer must be ordered. The ErgoNOW PA-12-XXYYZZ (Delrin), PA-13-XXYYZZ (Noryl), PA-14-XXYYZZ (Ultem 1000), or PA-15-XXYYZZ (PEEK) keyed retainer should be ordered to match the key code of the original SmartProbe connector or intended chemistry. SmartProbe and ErgoNOW keyed retainers are not interchangeable.

# **Tube Connections**

	OPTIONS	DESCRIPTION
Gas inlet	А	<sup>5</sup> / <sub>32</sub> " tube Quick Connect and gas fitting kit (see page 5 for additional gas fitting kit information)
	В	<sup>1</sup> /4" tube Quick Connect (no gas fitting kit)
	С	<sup>1</sup> /8" tube Quick Connect (no gas fitting kit)
	D	<sup>1</sup> /4" tube Swagelok® fitting (no gas fitting kit)
	E	<sup>1</sup> /8" FNPT thread with Quick Connect stem (no gas fitting kit)
	F	<sup>1</sup> /8" FNPT thread (no Quick Connect stem, no gas fitting kit)
	Z	No gas inlet fitting (only the tee fitting with PRV installed)




\*Reference ordering information on page 7.

## DIMENSIONS

For detailed information regarding ErgoNOW connector dimensions and other information, please reference the ErgoNOW Dispense Connector data sheet.

#### **ORDERING INFORMATION**

# 



Note: When upgrading a SmartProbe connector to an ErgoNOW connector, both the NA-117 upgrade kit of choice and an ErgoNOW replacement Keyed retainer must be ordered. The ErgoNOW PA-12-XXYYZZ (Delrin), PA-13-XXYYZZ (Noryl), PA-14-XXYYZZ (Ultem 1000), or PA-15-XXYYZZ (PEEK) keyed retainer should be ordered to match the key code of the original SmartProbe connector or intended chemistry. SmartProbe and ErgoNOW keyed retainers are not interchangeable.

#### ErgoNOW Dispense Connector Keyed Retainer Only: part number

(A replacement keyed retainer must be purchased in addition to the ErgoNOW upgrade kit when upgrading a SmartProbe connector to the ErgoNOW connector.)



PART NUMBER	PA-12-XXYYZZ*	PA-12-232122**	PA-13-XXYYZZ* AND PA-13-232122**	PA-14-XXYYZZ* AND PA-14-232122**	PA-15-XXYYZZ* AND PA-15-232122*
Materials of Construction	Delrin	Delrin	Noryl	Ultem 1000	PEEK
Contents	Retainer only	Retainer only	Retainer only	Retainer only	Retainer only
Retainer color	Black	Red	Black	Amber	Gray
Retainer image	Q	Ø	0	O	0

\* XXYYZZ represents the customer-specific key code

\*\* 232122 is the default key code

#### FOR MORE INFORMATION

Please call your Regional Customer Service Center today to learn what Entegris can do for you. Visit <u>entegris.com</u> and select the <u>Contact Us</u> link to find the customer service center nearest you.

#### TERMS AND CONDITIONS OF SALE

All purchases are subject to Entegris' Terms and Conditions of Sale. To view and print this information, visit <u>entegris.com</u> and select the <u>Terms & Conditions</u> link in the footer.



Corporate Headquarters 129 Concord Road Billerica, MA 01821 USA Customer Service Tel +1 952 556 4181 Fax +1 952 556 8022 Toll Free 800 394 4083

Entegris<sup>®</sup>, the Entegris Rings Design<sup>®</sup>, and other product names are trademarks of Entegris, Inc. as listed on <u>entegris.com/trademarks</u>. All third-party product names, logos, and company names are trademarks or registered trademarks of their respective owners. Use of them does not imply any affiliation, sponsorship, or endorsement by the trademark owner.

©2023-2025 Entegris, Inc. | All rights reserved. | Printed in the USA | 7119-11918ENT-0225