



SAVANA® 226/334 PS PLUS CARTRIDGE FILTERS

*PS filters for weak acid, bases and
ultrapure DI water filtration*

Overview

Savana® 226 and 334 PS Plus cartridge filters are high-flow, longer-lifetime filters that are ideally suited for filtration of weak acids, bases and ultrapure DI water for a wide range of applications in many industries.

Applications

- Various applications for weak acids, bases and ultrapure DI water
- Large format flat panel displays, DI water rinse after wet etching and stripping and cleaning processes
- Photovoltaic, chemical manufacturing, data storage and all electronics for larger format applications

Features and Benefits

- Asymmetric membrane structure provides high flow rates with lower differential pressure and a longer lifetime
- Hydrophilic PS media eliminates prewetting treatment, reduces filter changeout time and increases equipment uptime




- Provides excellent chemical compatibility with weak acids, bases and DI water
- Various retention ratings and types to meet unique processing needs

Specifications


		226 Cartridge Filters	334 Cartridge Filters
Materials:	Membrane	Hydrophilic polyethersulfone	
	Support, sleeve, caps, core	Polypropylene	
	O-ring	EPDM, FKM, E-FKM (AS568-226)	EPDM (U-cup or AS568-334) FKM (U-cup or AS568-334) E-FKM (AS568-334)
Retention rating:	0.1, 0.2, 0.45, 1.0 µm		
Operating conditions:	Maximum forward differential pressure	0.4 MPa (4 bar, 58 psi) @ 20°C (68°F)	
		0.12 MPa (1.2 bar, 17 psi) @ 90°C (194°F)	
	Maximum reverse differential pressure	0.25 MPa (2.5 bar, 36 psi) @ 20°C (68°F)	
	Maximum operating temperature	90°C (194°F)	
Dimensions (nominal):	Length	240 mm (9.45")	267 mm (10.51")
	Diameter	85 mm (3.35")	130 mm (5.12")

Savana 226 PS Plus Filters

Performance Data




Dimensions



Ordering Information


Savana 226 PS Plus Cartridge Filters

Part Number




Savana 334 PS Plus Filters

Performance Data




Dimensions



Ordering Information

Savana 334 PS Plus Cartridge Filters

Part Number



*Default U-cup for EPDM or FKM sealing material

For More Information

Please call your Regional Customer Service Center today to learn what Entegris can do for you. Visit www.entegris.com and select the Customer Service link for the center nearest you.

Terms and Conditions of Sale

All purchases are subject to Entegris' Terms and Conditions of Sale. To view and print this information, visit www.entegris.com and select the Legal Notices link from the footer.

Entegris®, the Entegris Rings Design®, Creating a Material Advantage® and Savana® are registered trademarks of Entegris, Inc.

ENTEGRIS, INC.

Corporate Headquarters | 129 Concord Road | Billerica, MA 01821 USA
 Customer Service Tel. +1 952 556 4181 | Customer Service Fax +1 952 556 8022
 In North America 800 394 4083 | www.entegris.com